

MAILBOX & POST INSTALLATION INSRUCTIONS


STEP 1: MOUNT BRACKET TO POST BY LINING UP THE BOLTS THAT ARE WELDED TO THE BRACKET WITH THE HOLES THAT ARE DRILLED IN THE POST ABOVE THE CASTING. BOLTS SHOULD GO ALL THE WAY THRU THE POST. USE CAP NUTS PROVIDED TO SECURE THE BRACKET TO THE POST

STEP 2: MOUNT MAILBOX THE BRACKET BY SETTING THE BOX DOWN OVER THE BRACKET RAILS. SECURE BY PLACING THE SHORT SCREW WITH WASHER THRU THE RAIL FROM UNDERNEATH THE BOX, THRU EACH HOLE ON THE MAILBOX (THERE WILL BE 2 HOLES ON EACH SIDE OF THE BOX) USE THE BRASS CAP NUTS ON THE OUTSIDE OF THE MAILBOX. TO TIGHTEN THE SCREWS AND CAP NUTS, HOLD THE CAP NUT WITH NEEDLE NOSE PLIERS ON THE OUTSIDE AND SCREW THE SCREW IN UNDERNEATH THE BOX USING A SCREWDRIVER. PLEASE DO NOT USE A WRENCH ON THE CAP NUTS BECAUSE IT WILL STRIP THE FINISH OFF OF THE MAILBOX ALL AROUND THE CAP NUT

STEP 3: DIG 18" DEEP HOLE AND FILL AT LEAST HALF WAY WITH CONCRETE MIXTURE

STEP 4: PLACE POST IN HOLE UP TO BOTTOM OF THE DECORATIVE CASTING AND MAKE SURE THE POST IS LEVEL.

STEP 5: AFTER THE CONCRETE HAS SET, FILL THE REST OF THE HOLE WITH THE DIRT FROM THE ORIGINAL HOLE



NOTE: IN REGIONS WHERE THE FROST LINE (FREEZING) IS LOWER THAN 18", IT MAY BE NECESSARY TO BURY A PIPE SLEEVE TO INSERT THE POST INTO TO INSURE STABILATY

COPPER SCULPTURES INC.		
DWG. TITLE: DECORATIVE STEEL MAILBOX & POST		
Drawn By: <i>RJM</i>	DWG NO.	INSTALL_MAILBOXPOST
Date: 12-5-07	SCALE: 1" = 1'-0"	JUST. NAME: REFERENCE